

Rejutor[™] Calibration Guidelines

Integrating the *Rejutor* – High-Precision Adjustable Resistor

1 Introduction

The *Rejutor*, an adjustable analog micro-resistor, from Microbridge Technologies represents a major technological improvement for analog compensation. *Rejutors* provide adjustment capability in both down and bi-directional mode. Down adjustment decreases the resistance of the *Rejutor*, in a range from 0 to at least 30% below the as-manufactured resistance. Bi-directional adjustment can be used to increase or decrease the resistance of the *Rejutor*, over a more limited range. The bi-directional adjustment range is dependent on position within the adjustment range. The maximum bi-directional adjustment range is 5% when the resistance is typically 30% below the as-manufactured value.

2 Going Down

Overall down adjustment range is from the as-manufactured resistance to at least 30% of that resistance. For example, a 10K Ω *Rejutor* has a down adjustment range from 10K Ω to below 7K Ω .

Figure 1, below, shows three examples of down adjustment. Sample 1 was adjusted by 29%. Sample 2 was initially adjusted 19%, and then adjusted down an additional 9% from that value. Sample 3 was adjusted 10% down. All three samples could be subsequently bi-directionally adjusted from those end-points. Samples 2 and 3 could be further adjusted down.

A *Rejutor* can be reduced to 70% of its as-manufactured value with a typical precision of 0.1% (as determined by Microbridge *Rejutor* Calibration Tools). However, practically speaking, in the first (upper) 10% it is only possible to decrease the resistance of the *Rejutor*. Bi-directional adjustment is easier after the *Rejutor* has traversed this first 10%.




Figure 1: Example of *Rejutor* Adjustment

[™] *Rejutor* is a trademark of Microbridge Technologies

Information furnished by Microbridge Technologies is believed to be accurate and reliable. However, no responsibility is assumed by Microbridge Technologies for its use, nor for any infringements of patents or other rights of third parties that may result from its use. Specifications subject to change without notice. No license is granted by implication or otherwise under any patent or patent rights of Microbridge Technologies. Trademarks and registered trademarks are the property of their respective companies.

3 Bi-directional Adjustment

Bi-directional adjustment is used for precision adjustment of the **Rejutor** and can be performed many times within a finite range. The bi-directional range depends upon the difference between the present resistance and the as-manufactured resistance. The bi-directional range increases as this difference increases.

This behavior is summarized in Figure 2. The initial portion of the graph shows a resistance decrease from the as-manufactured, in several steps (similar to Figure 1) to an overall decrease 'a'. After the resistance reaches the desired target range (shown by the square at *point 'e'*), bi-directional adjustment is possible within a range **above** that limit (the red line through *points 'c' and 'e'*). *Range 'b'* is the bi-directional range, which is dependent upon the size of 'a'. If the **Rejutor** is further reduced lower than the line at *points 'c' and 'e'* a new bi-directional range will be defined from that point.




Figure 2: Bidirectional Range - Example 1

Variations in the resistance adjustment range for a **Rejutor** are shown in Figure 3. Assume *Range 'a'* represents the ~30% range of a **Rejutor** and *Range 'b'* is the 5% bi-directional range near the bottom of that 30% zone. In that case *b'* and *b''* represent the bi-directional ranges available at ~15% and ~10% down from the as-manufactured resistance, respectively.

The bi-directional range at *b''* is limited since this is the transition from the upper 10%, where bi-directional adjustment is slower. The bi-directional range at *b'* is approximately 2 to 3% of the overall resistance of the **Rejutor**. (E.g. for a 10K Ω sample, the bi-directional range at *b'* is approximately 250 Ω .)




Figure 3: Bidirectional Range - Example 2

The relationship between bi-directional range and the amount of down adjustment from the as-manufactured value is shown below. The chart is based on a small number of samples, and should be viewed as a rough guideline to **Rejutor** bi-directional adjustability range.




Figure 4: Bi-directional Range versus Down Adjustment

4 Summary

The resistance of **Rejustors** is adjustable up or down in a range from the as-manufactured value to at least 30% lower. Bi-directional adjustment is generally available only after traversing the first 10% from the as-manufactured resistance. The bi-directional range increases as the difference between the present resistance and the as-manufactured resistance increases. **Rejustors** can be adjusted up 1.5% to 5% of the amount they were reduced from the as-manufactured value. Bi-directional adjustment can be performed many times without compromising range or precision.

Rejust-it software algorithms are designed to adjust slightly below the target and then fine-adjust to a precise target. The software enables up and down adjustment with down being easiest and quickest. It is important to understand **Rejustor** behavior when establishing targets, precision and pre-trim (if applicable).

Using *Rejust-it* software with reasonable care will ensure the adjustment process does not overshoot the target to such an extent that bi-directional adjustment to the target is no longer possible. These algorithms have been designed to achieve typical precision of 0.1% or better anywhere within the adjustable range.